

INSTALLATION INSTRUCTIONS

- ① Determine desired pattern, trace onto drywall and cut out pattern. Channel depth is conducive to not interfere with stud locations.
- ② Remotely locate 12V driver. Bring 2-wire low voltage (or 4-wire for RGB or 5-wire for RGBW) to one end of channel location.
- ③ Dry fit channel cut to size on site, bring wire through end of channel with feed end cap or drill hole through back of channel close to the end. Place solid end cap at other end. If connecting multiple channels slide the seamless connection bars into the bar guide groove halfway. Insert set screws to secure then add second channel piece and secure with set screw to ensure straight join of two pieces.
- ④ Add screws to hold channel in place. Mud over flange up to edge of channel creating a smooth transition to drywall and remove any excess mud from channel.
- ⑤ Wire in ribbon. Place ribbon in channel, use silicone to secure ribbon. (See wiring diagram for assistance)
- ⑥ Snap in the lens, cut to size on site.

