

INSTALLATION INSTRUCTIONS

① To be installed by a qualified electrician in compliance with the local building and electrical codes. Before installing turn off power.

② When used in some concrete applications, soil or gravel use with rough in housing (order separately). When used in drywall or wood housing is not required.

Cut appropriate hole size, insert housing if applicable and run low voltage wire to light location from accessible remotely located driver.

Recommended Hole Sizes:

Use with rough in housing: 41mm / 1-5/8"

Use without rough in housing: 35mm / 1-3/8"

③ Screw on trim. Make wire connection. Push light into hole or housing.

④ Turn power back on.

